Smart Pianist Supprted Instruments

Instrument		iOS	Android
Clavinova CSP	CSP-170	yes	yes
	CSP-150	yes	yes
Clavinova CLP	CLP-695GP	yes	yes
	CLP-685	yes	yes
	CLP-665GP	yes	yes
	CLP-675	yes	yes
	CLP-645	yes	yes
	CLP-635	yes	yes
Clavinova CVP	CVP-809GP	yes	-
	CVP-809	yes	-
	CVP-805	yes	-
TransAcoustic / Silent Piano	TA2	yes	yes
	SH2	yes	yes
	SC2	yes	yes
AvantGrand	N3X	yes	yes
	N1X	yes	yes
	NU1X	yes	yes
SCLP	SCLP-6450	yes	yes
	SCLP-6350	yes	yes
ARIUS	YDP-184	yes	yes
	YDP-S54	yes	yes
	YDP-S34	yes	yes
	YDP-164	yes	yes
	YDP-144	yes	yes
P	P-515	yes	yes
	P-125	yes	yes
	P-121	yes	yes
	P-128	yes	yes

Available functions for each instrument

Functions				Clavinova CSP CSP-170 CSP-150	Clavinova CLP CLP-695GP CLP-685	Clavinova CLP CLP-665GP CLP-675 CLP-645 CLP-635	Clavinova CVP CVP-809GP CVP-809 CVP-805	TransAcoustic / Silent Piano TA2 SH2 SC2	AvantGrand N3X	N1X	NU1X	SCLP SCLP-6450 SCLP-6350	ARIUS YDP-184	YDP-S34 YDP-S54 YDP-144 YDP-164	P P-515	P-125 P-121 P-128
Piano Room	Piano Room			yes	yes	yes	-	yes	yes	yes	yes	yes	yes	yes	yes	yes
	Piano Room Setting	Lid Position		yes	yes	yes	-	-	-	-	-	yes	yes	yes	yes	-
		Brightness		yes	yes	yes	-	-	-	-	-	yes	yes	-	yes	-
		Touch Curve		yes	yes	yes	-	yes	yes	yes	yes	yes	yes	yes	yes	yes
		Environment		yes	yes	yes	-	yes	yes	yes	yes	yes	yes	yes	yes	yes
		Master Tune		yes	yes	yes	-	yes	yes	yes	yes	yes	yes	yes	yes	yes
		VRM		yes	yes	yes	-	yes	yes	yes	yes	yes	yes	-	yes	-
		Damper Resonance		yes	yes	yes	-	yes	yes	yes	yes	yes	yes	yes (on/off only)	yes	yes (on/off only)
		String Resonance		yes	yes	yes	-	yes	yes	yes	yes	yes	yes	-	yes	-
		Aliquot Resonance		-	yes	yes	-	yes	-	-	yes	yes	yes	-	yes	-
		Body Resonance		-	yes	yes	-	yes	-	-	yes	yes	yes	-	yes	-
		Key Off Sampling		yes	yes	yes	-	yes	-	-	-	yes	yes	-	yes	-
		Half Pedal Point		yes	yes	yes	-	yes	-	-	-	yes	yes	-	yes	-
		Each Key Setting		yes	yes	yes	-	yes	yes	yes	yes	yes	yes	yes	yes	yes
Voice	Voice Select			yes	yes	yes	-	yes	yes	yes	yes	yes	yes	yes	yes	yes
	Layer			yes	yes	yes	-	-	-	-	-	-	yes	yes	yes	yes
	Left, Split Point			yes	yes	yes	-	-	-	-	-	-	yes	-	yes	yes
	Voice Setting	Octave		yes	yes	yes	-	-	-	-	-	-	yes	yes	yes	yes
		Mixer	Volume	yes	yes	yes	-	-	-	-	-	-	yes	yes	yes	yes
			Pan	yes	yes	yes	-	-	-	-	-	-	yes	-	yes	-
			Reverb	yes	yes	yes	-	yes	yes	yes	yes	yes	yes	yes	yes	yes
Style				yes	-	-	-	-	-	-	-	-	-	-	-	-
Song	Playback, FF, Rewind	(Audio Song)		yes	yes	yes	yes	yes	(sounds only from smart device)	yes	yes	yes	yes	yes	yes	yes
		(MIDI Song)		yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes
	AB Repeat	(Audio Song)		yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes
		(MIDI Song)		yes	yes	yes	yes	-	-	-	-	yes	yes	-	yes	-
	Guide (MIDI Song)			yes	-	-	yes	-	-	-	-	-	-	-	-	-
	Volume	(Audio Song)		yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes
		(MIDI Song)		yes	yes	yes	yes	yes	-	-	-	yes	yes	yes	yes	yes
	Tempo			yes	yes	yes	yes	yes (*1)	yes	yes	yes (*1)	yes	yes	yes (*1)	yes	yes (*1)
	Transpose	(Audio Song)		yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes
		(MIDI Song)		yes	yes	yes	yes	yes	yes	-	-	yes	yes	yes	yes	yes
	Part (MIDI Song)	Right, Left		yes	yes	yes	yes	yes	-	-	-	yes	yes	yes	yes	yes
		Backing		yes	yes	yes	yes	-	-	-	-	yes	yes	-	yes	yes
	Score/Chord/Lyric Screen			yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes
	Audio Song Analysis	Audio to Score		yes	-	-	yes	-	-	-	-	-	-	-	-	-
		Chord Analysis		yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes
	Chord Edit			yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes
		Copy, Delete, Undo		yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes
	Song Setting	Arrangement (Audio Song)	Audio to Score Setting	yes	-	-	yes	-	-	-	-	-	-	-	-	-
			Backing	yes	-	-	yes	-	-	-	-	-	-	-	-	-
			Melody Suppressor	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes
		Playback	Stream Lights / Guide Lamp	yes (Stream)	-	-	yes (Guide Lamp)	-	-	-	-	-	-	-	-	-
			Guide Type (MIDI Song)	yes	-	-	yes	-	-	-	-	-	-	-	-	-
			Quick Start (MIDI Song)	yes	yes	yes	yes	-	-	-	-	yes	yes	yes	yes	yes
			MIDI Part Channel (MIDI Song)	yes	-	-	yes	-	-	-	-	-	-	-	-	-
			Score, Chord, Lyric	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes
			Mixer	yes	-	-	yes	-	-	-	-	-	-	-	-	-
		Song Edit	Quantize (MIDI Song)	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes
			Delete, Mix, Setup (MIDI Song)	yes	-	-	yes	-	-	-	-	-	-	-	-	-
			Trimming (Audio Song)	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes
Recording	Audio Recording			yes	yes	yes	yes	yes	-	yes	yes	yes	yes	yes	yes	yes
	Audio Overdub Recording			yes	yes	yes	yes	yes	-	yes	yes	yes	yes	yes	yes	yes
	MIDI Recording			yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes
	MIDI Multitrack Recording			yes	-	-	yes	-	-	-	-	-	-	-	-	-
Metronome	Metronome			yes	yes	yes	-	yes	yes	yes	yes	yes	yes	yes	yes	yes
	Rhythm			-	yes	yes	-	-	-	-	-	yes	yes	-	yes	yes
		Bass On/Off		-	-	-	-	-	-	-	-	-	-	-	yes	yes
Balance				yes	yes	yes	-	yes	-	-	-	yes	yes	yes	yes	yes
Registration Memory				yes	yes	yes	-	yes	yes	yes	yes	yes	yes	yes	yes	yes
Utility	Transpose			yes	yes	yes	-	yes	yes	yes	yes	yes	yes	yes	yes	yes
	Tuning	Master Tune		yes	yes	yes	-	yes	yes	yes	yes	yes	yes	yes	yes	yes
		Scale Tune		yes	yes	yes	-	yes	yes	yes	yes	yes	yes	yes	-	-
	Keyboard Setting	Touch Curve		yes	yes	yes	-	yes	yes	yes	yes	yes	yes	yes	yes	yes
		TRS		-	-	-	-	yes	-	-	-	-	-	-	-	-
	Pedal Setting			yes	-	-	-	-	yes	-	-	-	-	-	-	-
		Function Assign	Score Page Turning	yes	yes	yes	-	-	yes	yes	yes	yes	yes	yes	yes	yes
			Half Pedal Point	yes	yes	yes	-	yes	yes	yes	yes	yes	yes	-	yes	-
		AUX Pedal Polarity		yes	yes	-	-	-	-	-	-	-	-	-	yes	-
	Mic Setting			yes	-	-	-	-	-	-	-	-	-	-	-	-
		Vocal Harmony		yes	-	-	-	-	-	-	-	-	-	-	-	-
	Master EQ			yes	-	-	-	-	-	-	-	-	-	-	-	-
	Sound Setting	Brilliance		-	-	-	-	yes	-	-	-	-	-	-	-	-
		Speaker Setting		yes	-	yes	-	-	-	-	-	yes	yes	yes	yes	yes
		Binaural / Stereophonic Optimizer		Binaural	Binaural	Binaural	-	Binaural	Binaural	Binaural	Binaural	Binaural	Stereophonic Optimizer	Stereophonic Optimizer	Binaural	Stereophonic Optimizer
		Lid Position / TA Mode Tone Control		-	-	-	-	yes (only TA2)	-	-	-	-	-	-	-	-
		IAC (Intelligent Acoustic Control)		yes	-	-	-	yes (only TA2)	yes	yes	yes	yes	yes	yes	-	yes
		AUX In Noise Gate		yes	-	-	-	yes	yes	yes	yes	-	-	-	-	-
	System	Version, Language, Manual, FAQ		yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes
		Audio Rec Format		yes	yes	yes	yes	yes	-	yes	yes	yes	yes	yes	yes	yes
		Dropbox		yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes
		Auto Power Off		yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes
		Firmware Version, Firmware Update		yes	-	-	-	-	-	-	-	-	-	-	-	-
		Factory Reset		yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes
		Backup, Restore		yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes
Demo				yes	-	-	-	-	-	-	-	-	-	-	-	-
Connection	Wi-Fi	UD-WL01		yes	yes	yes	yes	yes	-	yes	yes	yes	yes	-	yes	-
	USB cable (for iOS devices)	Lighting - USB cable		yes	-	-	-	-	-	-	-	-	-	-	-	-
		Lightning to USB Camera Adapter + USB cable (Type A male - Type B male)		-	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes
	USB cable (for Android devices)	USB On-The-Go adapter (Micro B male - Type A female) + USB cable (Type A male - Type B male)		yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes
		USB On-The-Go adapter (Type C male - Type A female) + USB cable (Type A male - Type B male)		yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes

(*1) Tempo can be changed while song is playing.